



CyberTouch™ 730

Multi-OS Scissor-Switch Desktop Keyboard



Model: AKB-730UW

QuickGuide

English

www.adesso.com

CONTENTS




AKB-730UW Keyboard



Quick Start Guide

KEYBOARD DESCRIPTION



LIMITED WARRANTY

Adesso provides a one year limited warranty for all of its products against defects in material and workmanship.

During this period, Adesso will repair or replace any product which proves to be defective. However, Adesso will not warranty any product which has been subject to improper freight handling, shipping abuse, neglect, improper installation or unauthorized repair. The warranty will not cover products installed with components not approved by Adesso and products where the sealed assembly trace has been broken.

If you discover a defect, Adesso will, at its option, repair or replace the product at no charge to you provided you return it during the warranty period with freight charges pre-paid to Adesso. Before returning any product, you must obtain a Return Merchandise Authorization number (RMA). This RMA # must be clearly marked on the outside of the package you are returning for warranty service. Be certain to also include your name, shipping address (no PO Boxes), telephone number, and a copy of the invoice showing proof of purchase in the package.

SUPPORT

We have listed most of our FAQ's (Frequently Asked Questions) at: <http://www.adesso.com/faqs.asp>. Please visit our FAQ Service & Support pages before you contact our E-mail or Telephone Support.


Email Support: If our FAQ's do not help you resolve your issues, please email support@adesso.com

Telephone Support:
Toll Free: (800) 795-6788
9:00AM to 5:00PM PST Monday - Friday

INSTALLATION

1. Make sure that your computer or available device is turned OFF before installing this keyboard.

2. **FOR USB CONNECTION:**
Plug in the TYPE-C cable to the available TYPE-C port.



3. Turn On your computer; operating system will detect the device automatically, no driver required.

INTRODUCTION

Adesso® CyberTouch™ AKB-730UW Multi-OS Scissor-Switch Desktop Keyboard is ideal for the home, office, or while on the go with it's Multi-OS layout. This keyboard combo features multi-functional hotkeys which can quickly access media player, multimedia controls, and Internet browser commands. It is designe with a slim and low-profile Scissor-Switch Technology for comfort, speed, and a better tactile feel.

FEATURES

- Keyboard Specifications:**
- Keyboard Layout: 104-Key US layout
 - Key type: Scissor Switch
 - Connection: USB TYPE-C
 - Hotkeys: 13 Hotkeys (CoPilot,Home , Back, Forward, Email, Search, Play/Pause, Stop,Previous Track, Next Track, Volume Up,Volume Down & Mute)
 - Keyboard Dimensions: 16.25 x 4.75 x 0.50" (436 x 122.8 x 11 mm)
 - Keyboard Weight: 1.4 Lbs (625g)

REQUIREMENTS

- Platform: Windows® 8 and above.
Mac os 10.4 and above
- Connnectivity Technology: TYPE-C port

Multimedia Hotkeys	
	Launches CoPilot
	Home
	Backward
	Forward
	Search
	Email
	Play / Pause
	Stop
	Previous Track
	Next Track
	Volume Up
	Volume Down
	Mute