



Open-Ear Sport Bluetooth Earbuds with LED Display




Model: Xtream T4

QuickGuide


English

www.adesso.com

CONTENTS



Overview



LIMITED WARRANTY

Adesso® provides a one year limited warranty for all of its products against defects in materials and workmanship.

During this period, Adesso® will repair or replace any product which proves to be defective. However, Adesso® will not warrant any product which has been subject to improper handling, abuse, negligence, improper installation or unauthorized repair. The warranty will not cover products installed with components not approved by Adesso® and products where the sealed assembly trace has been broken.

If you discover a defect, Adesso® will, at its option, repair or replace the product free of charge, provided you return it during the warranty period with freight charges pre-paid to Adesso®. Before returning any product, you must obtain a Return Merchandise Authorization number (RMA). This RMA # must be clearly marked on the outside of the package you are returning for warranty service. Be certain to also include your name, shipping address (no PO Boxes), telephone number, and a copy of the invoice showing proof of purchase in the package.

SUPPORT

FAQ's <https://www.adesso.com/faq.php>

Email Support: support@adesso.com

Telephone Support:

Toll Free: (800) 795-6788

9:00AM to 5:00PM PST Monday - Friday

Usage Instructions

1. Pairing the earbuds with your smartphone



Step 1: The earbuds will turn on automatically once they are taken out from the charging case, or long touch the panels of both earbuds to turn on manually.
Step 2: RED and BLUE LED will start blinking on both earbuds. Both of the earbuds will automatically pair with each other in 5 seconds.

Once they are paired with each other, one of the earbuds will show a RED and BLUE LED blinking alternatively, which means they are ready to pair with your smartphone.
Step 3: Now switch on Bluetooth in your smartphone and search for nearby devices and pair with the name: "Xtream T4", with voice prompt 'Connected' after the pairing is successful. Enter '0000' if prompted for password.

The earbuds will re-connect with smartphone automatically after first pairing.

Notes:

The L or R earbud can be used alone to pair with your smartphone, and thus only mono sound is available.

2. During Music Playback

- 2.1 Touch the L or R panel ONCE to Play / Pause the track
- 2.2 Touch the L panel TWICE to skip to Prev. track
- 2.3 Touch the R panel TWICE to skip to Next track
- 2.4 Long touch the L panel to skip to Volume down
- 2.5 Long touch the R panel to skip to Volume up
- 2.6 Touch the R panel THREE TIMES to trigger the Siri or Google Assistant.

INTRODUCTION

Experience the ultimate audio freedom with our Wireless Earbuds, featuring Bluetooth 5.3 technology for seamless connectivity and lossless sound. These Stereo Earbuds boast a Dual Mic Call function, ensuring crystal-clear conversations even in noisy environments. Compact in design, they fit snugly in your ears for all-day comfort. Effortlessly control your music and calls with intuitive Touch Control, while the ergonomic design ensures a secure fit during your busiest days. Elevate your listening experience with these high-performance earbuds.

SPECIFICATIONS

- Connectivity: Bluetooth
- Charging: USB-C
- Driver: 14.2 mm
- Music Playback: 5 hours
- Wireless Range: 10 meters
- Control Method: Touch
- Batteries: Earbuds 30mAh / Charging Case 300mAh
- Case Dimensions: 4.4"x 2.28"x 0.93" (112*58*23.5 mm)
- Weight: 0.16 lbs (72g)

REQUIREMENTS

Devices with Bluetooth Audio Connectivity

Touch screen: the earbuds can be also controlled through the touch screen of the charging case, like ANC modes, EQ style, Volume, Play/Pause, etc.

3. During Calls

- 3.1 Touch the L or R panel ONCE to answer the incoming call / end the call.
- 3.2 Touch the L or R panel for 2 seconds to reject the incoming call.

4. Charge the Earbuds & Charging Case

- 4.1 Put the earbuds in the charging case, the earbuds power off and start charging automatically. When the earbuds are charging, the earbuds LED glows RED, and the RED LED will turn OFF when they are fully charged.
- 4.2 When the Case is charging, the case LED indicator blinks, and LED glows when the case is fully charged.

Note: press and hold the RESET button, then choose to POWER OFF the charging case, when you plan to leave it unused for a long time.

Safety information

Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1. This product is not a toy. Keep it out of reach of children.
2. Keep product out of the reach of children and pets to avoid chewing and swallowing.
3. Please protect your ears against loud volume. Loud volume can damage your ears.
4. Bluetooth wireless technology operates within a range of about 10 m (30 feet). The maximum communication distance may vary depending on the presence of obstacles (people, metal objects, walls, etc.) or the electromagnetic environment.
5. Microwaves emitting from a Bluetooth device may affect the operation of electronic medical devices.
6. The unit is not waterproof. If water or foreign objects enter the unit, it may result in fire or electric shock. If water or a foreign object enters the unit, stop use immediately.