



4-Port USB 2.0 Hub



Model: AUH-2040

QuickGuide English

www.adesso.com

LIMITED WARRANTY

Adesso® provides a one year limited warranty for all of its products against defects in materials and workmanship.

During this period, Adesso® will repair or replace any product which proves to be defective. However, Adesso® will not warrant any product which has been subject to improper handling, abuse, negligence, improper installation or unauthorized repair. The warranty will not cover products installed with components not approved by Adesso® and products where the sealed assembly trace has been broken.

If you discover a defect, Adesso® will, at its option, repair or replace the product free of charge, provided you return it during the warranty period with freight charges pre-paid to Adesso®. Before returning any product, you must obtain a Return Merchandise Authorization number (RMA). This RMA # must be clearly marked on the outside of the package you are returning for warranty service. Be certain to also include your name, shipping address (no PO Boxes), telephone number, and a copy of the invoice showing proof of purchase in the package.

SUPPORT

We have listed most of our FAQ's (Frequently Asked Questions) at: <http://www.adesso.com/faqs.asp>. Please visit our FAQ Service & Support pages before you contact our E-mail or Telephone Support.


Email Support: If our FAQ's do not help you resolve your issues, please email support@adesso.com

Telephone Support:
Toll Free: (800) 795-6788
9:00AM to 5:00PM PST Monday - Friday

①


②

DESCRIPTION




INSTALLATION

1. Turn on your computer and let your computer load completely.



④

2. Insert the USB receiver into your computer's USB port. Your operating system will automatically detect the device. Your device is now ready for use.



REMOVING USB DEVICES

It is very important to remove USB devices properly in order to prevent any accidental loss of data or hardware damage. Please follow below steps to safely remove usb devices from your computer.

- 1. You should only remove usb devices when it is not in use.
- 2. Go to your system tray and right click on the usb device symbol



⑤

INTRODUCTION

The Adesso USB 2.0 4-Port Hub is light and compact making it extremely easy to carry with you on the go. This hub also comes with power saving switches on each individual ports to conserve power when usb devices are not in use. It is also plug and play across different operating system such as Windows® and MacOS®. With our daily lives becoming more dependent on usb devices, this usb hub will serve as the perfect usb peripheral to host your usb devices.

SPECIFICATIONS

Connection:	USB 2.0
Ports:	4 USB Ports
Transfer Rate:	480Mbps
Power Source:	USB or AC Adapter (Adapter Not included)
Dimension:	3.8" x 1.5" x 1.5" (96.5 x 38.3 x 38.3 mm)
Weight:	2.33 oz (0.15lbs) (66g)
Cable Length:	4 ft. (1.2m)


REQUIREMENTS

Operating System: Windows® 10 / 8 / 7, MacOS® 10.3 and above
Connectivity Interface: An Available USB port


CONTENTS



3. Now click "Eject" and you should now receive a message instructing you that it's safe to remove the usb device.



4. For MacOS® users, right click on the usb device symbol and click "Eject"



Note:

- 1. The above instruction is base on Windows® 10 & MacOS® 10.12.6. Your screen might look differently depending on your operating system, but the on screen instructions will look similar.
- 2. If you find yourself needing more electrical power due to usage of high power usb devices, you can also obtain an AC power adapter to provide additional power.

⑥