



Adesso Cybertrack 1200

Document Camera



Model: Cybertrack 1200

QuickGuide

English

Limited Warranty

ADESSO provides one year limited warranty for the quality of all its products in materials and workmanship.

During this period, ADESSO will repair or replace all merchandise, which proved to be defective. However, ADESSO will not warranty any product which has been subjected to improper freight Handling, shipping abuse, neglect or unauthorized repair or installation. The warranty also will not cover products installed with Non-ADESSO components and product with broken sealed and assembly trace. After replacement of RMA, ADESSO reserves the right to request the total cost of the replacement products with broken seals or assembly trace.

If you discover a defect, Adesso will, at its option, repair or replace the product at no charge to you, provided you return it during the warranty period with transportation charges pre-paid to Adesso. You must contact Adesso at support@adesso.com for a Return Merchandise Authorization number (RMA) prior to returning any product. For each product returned for warranty service, please include your name, shipping address (no P.O. Box), telephone number, copy of the bill of sale as proof of purchase and have the package clearly marked with your RMA number.

Support


FAQ's: <http://www.adesso.com/faqs>

Email Support: support@adesso.com

Telephone Support:
Toll Free: (800) 795-6788
9:00AM to 5:00PM PST Monday - Friday

Overview

Before use, make sure the following items are included in the package. If anything is missing, contact the retailer where you purchased the Cybertrack 1200 product.




Specification

Image Sensor:	12.0 Megapixel CMOS Color Sensor
Interface:	USB 2.0
Image File Format:	JPEG
Doc File Format:	DOC, PDF, XLS, TXT
Video File Format:	AVI, MP4, FLV, WMV
Shooting Area:	Up to A4 Size - 8.3 x 11.7" (297 x 210mm)
Focus:	Auto Focus
Operating Dimension:	10.24 x 3.15 x 7.87" (260 x 80 x 200mm)
Weight:	1.54 lbs
Power:	5V by USB Powered

Hardware Installation

1. Plug the supplied USB cable to the back of the cybertrack 1200 and connect other end into an available USB port on your computer.



2. Adesso Cybertrack 1200 will connect automatically to your computer. (Adesso Cybertrack 1200 is a driverless device used with Windows 10, 8, 7, Vista or XP operating systems. Your computer will recognize the device under the Cameras in the Windows Device Manager menu.)

Getting Started

1. To start the program, please double click on the Adesso Cybertrack Software icon on the desktop or click Start Menu Windows icon then [All apps] to select Adesso Cybertrack Software.
2. Place a document on the position pad and align to position mark.
3. Select one of function to scan your materials from the main menu. You can make changes for your preferences in the settings menu and then click [Scan] button for scan a document.

Software Functions

Function Modes	Icons	Descriptions
Video		The Video mode is using for record video clip and save to different video formats with Motion JPEG compression. You can even use the video mode as a Visualizer.
Photo		The Photocopy mode is using for scan documents and print them to a printer. (NOTE: Need to work with a separate printer)
Document		The Document mode is using for scan documents, name cards, ID cards or any paper sheets to JPEG or PDF files.
OCR		The OCR mode can convert the scanned files into editable
Edit		The Edit mode allows you to adjust any document, PDF, JPEG files to your preference.
PDF		The PDF mode allows you to scan any document into a PDF file.
Email		The E-mail mode is using for scan and save result into PDF or JPEG files, and then send these files through E-mail.

