

#### USB Stereo Headset with controller



Model: Xtream P7P-TAA

# Quick **Guide**

www.adesso.com

#### **LIMITED WARRANTY**

Adesso provides a one year limited warranty for all of its products against defects in material and workmanship

During this period, Adesso will repair or replace any product which proves to be defective. However, Adesso will not warranty any product which has been subject to improper freight handling. shipping abuse, neglect, improper installation or unauthorized repair. The warranty will not cover products installed with components not approved by Adesso and products where the sealed assembly trace has been broken.

If you discover a defect, Adesso will, at its option, repair or replace the product at no charge to you provided you return it during the warranty period with freight charges pre-paid to Adesso. Before returning any product, you must obtain a Return Merchandise Authorization number (RMA). This RMA # must be clearly marked on the outside of the package you are returning for warranty service. Be certain to also include your name, shipping address (no PO Boxes), telephone number, and a copy of the invoice showing proof of purchase in the package.

FAQs: https://www.adesso.com/faqs/ Email Support: support@adesso.com **Telephone Support:** (800) 795-6788 9:00AM to 5:00PM PST MONDAY - FRIDAY

## INTRODUCTION

Xtream P7P stereo headphones offer an exceptional audio experience They come with convenient button controls for easy operation. The buttons support Push to Talk functionality, enabling complete control. The answer/end call feature allows for effortless communication. You can also control the volume level as needed. Enjoy high-quality sound and smart control with these headphones.

#### Features:

USB-C or USB-A Connection:

• Inline Controller: Push To Talk, Volume +/-, Answer/End Call • Unit Driver: 40mm

20Hz-20KHz · Frequency: 110dB ± 3dB · Sensitivity: · Impedance: 32 ohm Built-in Mic: Unidirectional • Dimension: 155\*55\*170MM 0.3 lbs (140g) Net Weight: · Cord Length: 6.23 ft (1.9m)

#### **REQUIREMENTS:**

#### **Operating System:**

• Operating System: Windows® 11/10/8 / 7, Mac Os® and above Android , Chrome

Adjust headset by sliding headband open or closed on both sides.


#### Connectivity Interface:

Available USB-C

HEADSET FIT

• USB C to USB A adapter

#### **DESCRIPTION**



**How to use Push To Talk?** 

Instantly transmit your voice with push-to-talk streamlining

communication and enhancing collaboration. Simple and

intuitive, it enables flexible control of the microphone for

To get started, open any application or answer any phone

transmit your voice, press and hold the push to talk button

on the control box while speaking. Once you are ready to

end your audio transmission, let go of the button and all

audio will stop transmitting from your microphone

call that uses your microphone. When you are ready to

different scenarios

A Green LED will light up when th Push To Talk button is being held

Get started with Push To Talk

### **CONTENTS**

1



USB-C to USB-A



2


User Guide

#### **GETTING STARTED**

#### CONNECTING THE HEADSET


Connect via USB-C

1. Plug the USB-C connector into your computer USB-C port.



Connect via USB-A

- 1. Plug the USB-C connector into the USB-A adapter
- 2. Plug the USB-A connector into your computer USB-A port. Note: Only use the USB-A adapter with the provided headset



answer/end call button when receiving a call to answer, once you have answered the call you will use the push-totalk button to transmit your voice. When you are finished with the call, you will press the answer/end call button to end the call.



on the side of the headset.

ADJUSTING THE MICROPHONE BOOM

1. Microphone boom rotates 130 degrees. Wear it on left side. For the best music experience, we recommend wearing the headset

with the microphone on the left. Left/Right indicators can be found

2. Adjust flexible microphone boom location to capture voice better.



# 6

3

# How to use the Answer/End call button?

To use the Answer/End call button, you simply press the




#### Troubleshooting

- 1. My microphone is not working.
- Make sure you are holding the push to talk button
- 2. I can't hear any sound.
- Please make sure your volume is not set to mute.
- 3. I keep receiving a microphone is muted error, even when pressing the push to talk button.
- Please check your Microphone properties to unmute.
- 4. My PC/Laptop does not have a USB-C port, how do i use the headset?
- Depending on which ports you have, use the USB-A or AUX adapters
- 5. I can't find the driver to download.

(8)

This headset is plug and play with no extra driver needed.



7



9